# 100 KHz to 3 GHz, 2 probes

# 3 AXIS RADIO FREQUENCY

# **ELECTROMAGNETIC FIELD METER**

Model: EMF-839 *ISO-9001, CE, IEC1010* 





The Art of Measurement

## 3 AXIS RF ELECTROMAGNETIC FIELD METER

Model: EMF-839

#### **FEATURES**

1 L/ (1 G) (LG				
* 3 Axis probe.				
* Wide measuring frequency ranges, 100 KHz to 3 GHz.				
* Radio frequency electromagnetic field tester.				
* EMF-839 is used for broadband devices of monitoring				
the wide range radio frequency electromagnetic field				
value.				
* For precision measurement consideration, the meter				
are included two probes :				
EP-04L ( Low frequency Probe, 100 KHz to 100 MHz )				
EP-03H ( High frequency Probe, 100 MHz to 3 GHz )				
* Unit : V/m, W/m^2, mW/cm^2.				
* Alarm setting function can warn the user if the				
measuring antenna is too near the strong radiation				
sources, the buzzer will sound to remind the user.				
* Peak hold function to latch peak value.				
* Data hold function to lock the current reading.				
* RS232 computer interface.				
* Real time data logger, build in clock ( hour-MIN-sec.,				
year-month-date ).				
* Auto or manual data record, 16,000 Data logger no.				
* Wide sampling time adjustment range from one second				
to 8 hours 59 minutes 59 seconds.				
* Compact metallic carry case.				
* Large size LCD with contrast adjustment, which can fit				
best viewing angle.				
* Microcomputer circuit provides special function & offers				
high accuracy.				
* Powered by 006P DC 9V battery or DC 9V adapter.				

#### **APPLICATIONS**

This meter is specially developed for measuring or monitoring electromagnetic field, for example: cell-phone station, hospital equipment, radar, micro-wave oven, radiation work, TV antenna, Radio station, welding equipment, baking-equipment, television, computer, factory, laboratory, and other environment...etc

#### SAFETY INSTRUCTIONS

### Danger

- For worker's safety, be aware that persons with electromagnetic implant ( e.g. cardiac-pacemarker ) are subject to especial danger in some case.

  Particular to observe the local safety regulations of the
- operator of the equipment.
- Before using the device, it need to know that how to setting " alarm-limit " value.

#### Attention

- Claims by some scientists that long term exposure to electromagnetic field may be the cause of childhood leukemia & other forms of cancer.
- Complete answers to any of these and related questions are not currently available. At the present time the most common practice is to avoid excess exposure over long period of time.
- Complete answers to any of these and related " Prudent Avoidance " as stated by the Environmental Protection Agency(EPA) USA is recommended.
- According to ICNIRP of reference levels to time-varying electromagnetic fields, The E-field strength levels are:

#### General public

Frequency range	e-field strength (V/m)			
3 to 150 kHz	87			
0.15 to 1 MHz	87			
1 to 10 MHz	87/f^1/2			
10 to 400 MHz	28			
400 to 2000 MHz	1.375 x f^1/2			
2 to 300 GHz	61			

#### Occupational

Frequency range	e-field strength (V/m)			
65 to 1000 kHz	610			
1 to 10 MHz	610/f			
10 to 400 MHz	61			
400 to 2000 MHz	3 x f^1/2			
2 to 300 GHz	137			

#### **GENERAL SPECIFICATIONS**

	SPECIFICATIONS				
Circuit	Custom one-chip of microprocessor LSI circuit.				
Display	LCD size: 58 mm x 34 mm.				
Measurement	V/m, mW/cm^2, W/m^2.				
Unit					
Accuracy	< 2 dB.				
Probe structure	3 Axis.				
Probe Type	EP-03H : 100 MHz to 3 GHz.				
Selection	EP-04L : 100 kHz to 100 MHz.				
Probe Input	50 OHM				
Impedance					
Frequency	EP-03H: 900 MHz, 1 GHz, 1.8 GHz,				
Selection	2.4 GHz, 2.45 GHz, 3 GHz.				
Points	EP-04L: 100kHz, 200kHz, 500kHz, 1MHz, 10MHz, 13.56MHz, 100MHz.				
Sensor	Semiconductor				
Structure	Johnsonductor				
Sampling Time	Manual Press the data logger button				
of Data Logger	once will save data one time.				
o. Data Loggo.	* Set the sampling time to				
	0 second				
	Auto 1 sec to 8 hour 59 min. 59 sec.				
Data Hold	Freeze the display reading.				
REC Function	Record Maximum & Minimum value.				
Power off	Auto shut off saves battery life or				
l ower on	manual off by push button.				
	* Can default auto power off or manual				
	power off.				
	* When default auto power off ,				
	power will off automatically after				
Deel, Held	10 min. if no button be pressed.				
Peak Hold	To latch the peak measurement value.				
Alarm Setting	Buzzer will sound when display over the setting value.				
Camandia a Times	Approx. 1 second.				
Sampling Time	Approx. 1 second.				
Low Battery	When display show Low battery				
	Approx. 1 second.  When display show Low battery Indicator, it should change the batteries.				
Low Battery Indicator Data Output	When display show Low battery Indicator, it should change the batteries. RS 232 PC serial interface.				
Low Battery Indicator Data Output Operating	When display show Low battery Indicator, it should change the batteries.				
Low Battery Indicator Data Output Operating Temperature	When display show Low battery Indicator, it should change the batteries. RS 232 PC serial interface. 0 to 50 ℃.				
Low Battery Indicator Data Output Operating Temperature Operating	When display show Low battery Indicator, it should change the batteries. RS 232 PC serial interface.				
Low Battery Indicator Data Output Operating Temperature Operating Humidity	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.				
Low Battery Indicator Data Output Operating Temperature Operating	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )				
Low Battery Indicator Data Output Operating Temperature Operating Humidity	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument :				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type. DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument: 200.0 x 76.2 x 36.8 mm				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 ℃.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 ℃.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm ( diameter) x 290 mm ( length)				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm (diameter) x 290 mm (length)  Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm ( diameter) x 290 mm ( length)  Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm (diameter) x 290 mm (length)  Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm ( diameter) x 290 mm ( length) Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 ℃.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm (diameter) x 290 mm (length)  Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 ℃.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument: 200.0 x 76.2 x 36.8 mm  Probe: 70 mm (diameter) x 290 mm (length) Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories Included	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 ℃.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm (diameter) x 290 mm (length)  Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories Included	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm (diameter) x 290 mm (length)  Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories Included	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm ( diameter) x 290 mm ( length)  Instruction manual				
Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply  Power Current Weight Dimension  Accessories Included	When display show Low battery Indicator, it should change the batteries.  RS 232 PC serial interface.  0 to 50 °C.  Less than 80 %RH.  DC 9 V battery ( 006P )  * Heavy duty or Alkaline type.  DC 9V adapter input.  Approx. DC 5.95 mA  523 g/ 1.16 LB.  Main instrument:  200.0 x 76.2 x 36.8 mm  Probe:  70 mm (diameter) x 290 mm (length)  Instruction manual				

## ELECTRICAL SPECIFICATIONS (23 ± 5 °C)

Strength Range	Resolution		Effective Value				
0~200.00 V/m	0.01 V/m		> 1 V/m				
0~99.999 W/m^2	0.001 W/m^2		> 0.03 W/m^2				
0~9.9999 mW/cm^2	0.0001 mW/cm^2		> 0.0003 mW/cm^2				
Frequency range	Accuracy	Cal.	level	Probe no.			
*100 KHz to 100 MHz	< 2 dB	30 V/m		EP-04L			

## Remark

- \* EP-04L probe's accuracy is specified within 400 KHz to 100 MHz only. If measurement frequency range is < 400 KHz, the reading value just for reference only.
- EP-03H probe's accuracy is specified within 100 MHz to 2.5 GHz only. If measurement frequency range  $\,$  is < 100 MHz or > 2.5  $\,$ GHz, the reading value just for reference only.
- \* For precision measurement consideration, it should select the " Frequency Team point " near the frequency value of measuring object.

Appearance and specifications listed in this brochure are subject to change without notice

NCC (National Communication Commission is the official organization on behalf Taiwan government)

# NCC RECOMMEND EMF-839, EMF-819 for Mobile station measurement



NCC Website: http://www.ncc.gov.tw